INSTALLATION AND OPERATION MANUAL

MODEL 2001B TYPE X PRESSURIZATION SYSTEM

PEPPERL+FUCHS

PROTECTING YOUR PROCESS

Table of Contents

Page 2 **System Purpose and Description**
Purpose, System description, Important notes

Page 3 **Identifying Your System**
Defines specific features of the system

Page 3 **General Information**
System & material specifications, Spare parts, Tools & test equipment, System accessories

Page 4 **Enclosure and Device Design**
Design requirements, Adjacent enclosures, Device ventilation, Temperature limitations

Page 5 **Installation Overview**
Installation diagram

Page 6 **Getting Started**
Establishing connection sizes, Determining enclosure inlet & outlet connection locations

Page 7 **System Mounting**
LH, RH, TM, BM & WM configurations, FM & PM configurations

Page 8 **Hardware Mounting**
Optional enclosure protection vent, Warning nameplates

Page 9 **Mounting Plate Dimensions**
Mounting plate dimension diagrams

Page 11 **Pneumatic Tubing Requirements**
Protective gas supply requirements, Pneumatic connection requirements

Page 12 **Tubing Connection Points**
LH, RH, TM, BM, WM, FM, & PM configurations

Page 13 **Tubing Installation**
LH, RH, TM, BM, WM, FM & PM tubing configurations

Page 14 **Electrical Supply Requirements**
General wiring requirements, EPCU power & alarm signal, Enclosure wiring methods & connections

Page 15 **Electrical Power Control Unit**
General layout & conduit connection points

Page 16 **EPCU Power Rating**
Power rating nameplate, Assembled electronics

Page 17 **Electrical & Pneumatic Diagrams**
LH, RH, TM, BM, WM, FM, & PM configurations

Page 18 **Conduit Installation**
EPCU electrical conduit, Optional intrinsic safety Barrier conduit and EPCU conduit connection parts

Page 19 **Power Modules & Wiring Diagram**
EPCU 120/220 VAC & 24-48 VDC power modules

Page 20 **Logic Module & Barrier Wiring**
Optional ISB wiring requirements & diagram, EPCU power control modes

Page 21 **Barriers & Field Adjustments**
ISB description & factory programming, LED display indicators, Timer functions & settings

Page 22 **Set-Up Procedure**
Pressurization set-up

Page 23 **Operating Sequence**
Class II pressurization operation

Page 24 **Troubleshooting Procedures**

Page 25 **Warranty and Liability Statements**
Warranty notes, General terms, Limitations

Page 26 **System Maintenance**

Page 27 **Systems Identification & Application Information**

Purpose and Description

Purpose

Pepperl+Fuchs' Bebco EPS System allows the use of general-purpose or nonrated electrical or electronic devices, with exception to devices that produce excessive heat, utilize combustible gas, or expose arcing contacts to the hazardous atmosphere, in NEMA (National Electrical Manufacturers Association) 4 or 12 enclosures in the place of explosion proof NEMA 7 enclosures. Other purposes include heat, moisture and dust contamination prevention.

Description

Model 2001B is an enclosure pressurization system that operates on a supply of compressed instrument air or inert gas. It regulates and monitors pressure within sealed (protected) enclosures, to prevent combustible dust accumulation within the enclosure(s). Intended exclusively for Class II areas, the system is designed to maintain a “safe” (1.0") pressure on one or more enclosures not exceeding a total volume of fifty cubic feet. In addition, the system includes an electrical power control unit (EPCU) that monitors system operation and controls enclosure power. These processes reduce the hazardous (classified) area rating within the enclosure(s), in accordance with the NEC - NFPA 70, Article 500, NFPA 496 and ISA12.4

Important Notes

One (1) permanent file copy and one (1) operations copy of this manual must be studied and retained by the operator of this system. User’s agents are responsible for transferring this manual to the user, prior to start-up.

The contents of this manual have been arranged to allow the use of this product as a stand-alone device on equipment and enclosures supplied by the user or its agents. The manual’s parameters encompass a combination of both National Fire Protection Association (NFPA) requirements and Pepperl+Fuchs, Inc. requirements. Pepperl+Fuchs therefore acknowledges the use of NFPA 496 as a guideline, that we have enhanced certain NFPA requirements and that additional information has been compiled to complete this document. The manual is intended as a complete guide and must be considered, unless specifically stated otherwise, that all directives contained herein are requirements for safe, practical and efficient use of this product.

This system is not intended for use to protect enclosures or devices that contain ignitable concentrations of gases or vapors. This exclusion generally applies to process or product analyzing systems equipment.

All specifications are subject to change without notice.

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Identifying Your System

This enclosure protection system is offered in various styles. For proper installation and operation, examine the system model number nameplate to identify the system style, area classification, and type, as noted below.


Model 2001B-STD-CII Type X
50 CUBIC FEET MAXIMUM ENCLOSURE VOLUME
CLASS II, DIVISION 1, GROUPS E, F & G TO NONHAZARDOUS
T3C
PURGE CONTROL FOR USE IN HAZARDOUS LOCATIONS. CLASSIFIED BY UNDERWRITERS LABORATORIES INC.® IN ACCORDANCE WITH THE NATIONAL FIRE PROTECTION ASSOCIATION STANDARD FOR PURGED AND PRESSURIZED ENCLOSURES FOR ELECTRICAL EQUIPMENT NFPA 496-1996
4S11
APPROVED BY FM APPROVALS AS ASSOCIATED TYPE X PRESSURIZATION CONTROL EQUIPMENT FOR USE IN HAZARDOUS LOCATIONS. REDUCES THE INTERNAL AREA OF A CONNECTED ENCLOSURE IN ACCORDANCE WITH DRAWING NUMBER MCL 2001B.

2001B - STD - CII - NR - LH - ##

Series Model Number

System Style
STD - Standard

Area Classification
CII - Class II, Group E, F & G Area

Power Control Mode
NR - Normal Running
CB - Conditional Bypass

Mounting Configuration

LH	- left hand	left side of enclosure
RH	- right hand	right side of enclosure
TM	- top mount	top of enclosure
BM	- bottom mount	bottom of enclosure
WM	- wall mount	wall surface
FM*	- frame mount	external frame or rack
PM*	- panel mount	enclosure surface cutout

** FM & PM configurations feature flush mount EPCU.*

- Additional factory installed accessories

General Information

System Specifications

System dimensions:	See pages 9 & 10
Shipping weight (lbs.):	38
Operating temp. range:	-20 °F to +120 °F
Supply pressure range:	* 5 -120 psi max.
When using the optional inline filter, max. supply pressure is 80 psi	
Supply requirements:	Clean air or inert gas
Safe pressure setpoint:	1.0" @ safe pressure
Safe pressure flowrate:	** 0.1-3.5 SCFH
System supply port:	3/8" tube fitting
Enclosure supply fitting:	3/8" tube fitting
Enclosure reference fitting:	1/4" tube fitting
EPCU conduit port size:	1/2" FPT
EPCU power requirements:	120 VAC 60 Hz 1Ø
(European 240 voltage only)	240 VAC 50 Hz 1Ø
EPCU power consumption:	500 mA
Power relay contacts:	20 Amps @ 240 VAC
	20 Amps @ 28 VDC
	20 Amps @ 48 VDC
Alarm relay N.O. contact:	20 Amps @ 240 VAC
	20 Amps @ 28 VDC
Alarm relay N.C. contact:	15 Amps @ 240 VAC
	10 Amps @ 28 VDC

* With EPV-3 vent - 120 psi max. to 5 psi minimum
Without EPV-3 vent - 5 psi maximum

In order to comply with the NFPA 496 standard requiring protection against over pressurization of the protected enclosure, the installer must install one of the following items in addition to the enclosure protection system.

a) Install an EPV-3 enclosure protection vent on the protected enclosure.

b) Install a tamper-proof regulator upstream of the enclosure protection system's system supply inlet to pre-regulate protective gas supply to 5 psi max.

** Enclosure integrity determines actual flow rate

Material Specifications

Regulator body:	Zinc w/ enamel finish
Regulator handle:	Polycarbonate
Enclosure pressure gauge:	Aluminum w/ enamel finish
Tube fittings:	316 SS forged body
Tubing:	316 SS 1/4" .035 welded
System nameplates:	Silkscreened Lexan® & SS
Fastener hardware:	Stainless steelscrews & bolts
Mounting plate:	316 14 ga #3 brush SS
EPCU enclosure body:	Bead blast cast alum.
Enclosure warning nameplate:	Silkscreened SS

Lexan® is a registered trademark of the General Electric Corporation

Recommended Spare Parts

Qty	Description	Part # (supercedes)
1	Enclosure pressure indicator	513235 (001027)
1	Enclosure pressure control regulator	513236 (002050)
1	Safe pressure switch	510357 (005205)
1	Series 2000 logic module-Ver. 2.0	510279 (005000)
1	Series 2000 VAC power module	510304 (005020)
1	Series 2000 VDC power module	510305 (005021)
1	Installation & operation manual	129-0209
1	Enclosure warning nameplate-CII	513009 (EWN-2)

Reference part number above for current spare parts pricing. Immediate pricing is available to all confirmed customers.

Installation Tools & Testing Equipment

1/2" chuck drill

Complete set of drill bits

1/2" & 1" conduit knockout punch or 1.375" hole saw

Complete set of tubing, conduit bending, instrument fitting and electrical craftsman hand tools

0 - 250 scfh flowmeter (connected upstream of protection system to determine air consumption and flow during set-up)

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Model 2001B System Accessories

Optional Enclosure Protection Vents

EPV-3-SA-00	Straight w/ spark arrestor
EPV-3-SA-90	Rt angle w/ spark arrestor

Additional Items

SMK -2, -3 or -10	System mounting kit
RAH	Div. 1 remote alarm horn
RAB-1	Div. 1 remote alarm beacon
RAB-2	Div. 2 remote alarm beacon
LCK	L fitting conduit kit
TCK	T fitting conduit kit
TR-10G	Tamperproof regulator w/ gauge
SRM-4000	Switch resistor module
NJ...	P+F NAMUR sensor
EFC-4	1/4" flush connector
EFC-6	3/8" flush connector
EBC-6	3/8" bulkhead connector
EPC-13	1" pipe connector
IS1	Channel A barrier
IS2	Channel B barrier
IS3	Channel C barrier
RP1	Redundant safe pressure switch
L	Power switch key lock assembly

Enclosure & Device Design

Enclosure Design Requirements

1. All windows must be shatterproof and sized as small as possible.
2. All NFPA 496 required markings must be placed on or near all enclosure doors and covers.
3. The enclosure must withstand an internal pressure of five (5) inches of water without sustaining permanent deformation and resist all corrosive elements in the surrounding atmosphere.
4. All lightweight objects in the enclosure, such as paper or insulation, must be firmly secured.
5. The enclosure should be constructed from materials such as metal or nonstatic polycarbonate to meet or exceed NEMA 4 or 12 performance requirements, but does not require third party approval.
6. The installation of obstructions or other barriers that block or impede the flow of protective gas must be avoided.
7. The creation of air pockets or other areas that trap flammable gases within the enclosure or devices must be avoided.
8. The enclosure should be located in an area where impact hazards are minimal.
9. If the enclosure is nonmetallic and contains equipment that utilizes or switches power loads greater than 2500 VA, it must be constructed from substantially noncombustible materials, such as materials designed to meet or exceed ANSI/UL94 ratings of 94 V-0 or 94 5V.

Adjacent Enclosures

1. Adjacent enclosures must be protected by one of the following means:
   a) purged or pressurized in series with the protected enclosure
   b) purged or pressurized separately
   c) protected by other means; e.g., explosion proof enclosures, hermetically sealed devices or intrinsic safe circuits
2. Adjacent purged or pressurized enclosures must be designed to meet all construction requirements above.

Total Volume Calculation

1. The total volume of all pressurized enclosures, devices and wireways must be considered.
2. All enclosure, device, and wireway volumes must be calculated without consideration of internally consumed space.

Device Ventilation

1. Enclosed devices within the protected enclosure which do not exceed 1.22 in^3 of free volume do not require ventilation to the protected enclosure.
2. If the free volume of an internal device exceeds 1.22 in^3 it must be protected by one of the following means:
   a) ventilated on the top and bottom sides with 1 in^2 of opening for each 400 in^3 of volume within the internal protected enclosure, at a minimum diameter of 1/4"
   b) purged in series with the protected enclosure or be purged separately or
   c) protected by other means; e.g., explosion proof enclosures, hermetically sealed devices, or intrinsic safe circuits.

Temperature Limitations

1. The enclosure must have no surface area that exceeds 80 percent of the flammable or ignitable substance's auto-ignition temperature.
2. Internal devices that exceed this temperature must be protected by one of the following manners:
   a) The device is enclosed in a chamber that is $_{C}UL_{US}$ or FM listed as a hermetically sealed device that prohibits the entrance of a flammable or ignitable substance, and maintains a surface temperature below temperature limits.
   b) It can be proven by testing that the devices will not ignite the substance involved.
   c) The device is purged in a separate enclosure that bears an ETW (enclosure temperature warning nameplate). Devices may be accessed only after power has been removed and the device has been allowed to cool to safe temperature, or the area is positively known to be nonhazardous.

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Installation Overview

Model 2002-STD-CI-LH Shown



Part No. 512246 Drawing No. 129-0209a 03/09

Getting Started

Typical Single Protected Enclosure Connections



	A	B	C	D	E
Description	**System supply tubing**	**Enclosure supply**	**Enclosure reference**	**Multi - enclosure connections**	**Optional remote venting**
***Tubing or pipe diameter**	3/8" O.D. tubing fully reamed	3/8" O.D. tubing fully reamed	1/4" O.D. tubing fully reamed	1" I.D. pipe fully reamed	1" I.D. pipe fully reamed
Maximum tubing / pipe length and maximum number of bends / elbows	20 feet 10 bends	5 feet 5 bends	20 feet 10 bends	10 feet 5 elbows	30 feet 5 elbows

TYPICAL MULTIPLE PROTECTED ENCLOSURE CONNECTIONS



*NOTE: Tube and pipe sizes are trade sizes and are not equal in inside diameter.
DO NOT substitute tube for pipe with same trade size.

HELPFUL HINTS

To ensure adequate protective gas flow to the protected enclosure(s), all piping and tubing must be fully reamed.

Precautions must be taken to prevent crimping and other damage to protective gas piping and tubing.

When protecting multiple enclosures with a single enclosure protection system, the enclosures must be connected in series from the smallest to the largest to ensure adequate protective gas flow.

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS
PROTECTING YOUR PROCESS

System Mounting

IMPORTANT NOTES

The system should be mounted at EYE LEVEL.

Care must be taken to ensure the system and all protruding components are clear of all enclosure accesses (doors and covers) and conduit, pipe, tubing or cable entries.

LH, RH, TM, BM and WM configurations are intended for mounting adjacent to the protected enclosure.

LH, RH, TM & BM configurations are also suitable for 2" schedule 40 pipe mounting.

Determine the mounting configuration of your system using the diagrams on pages 9 & 10.

Remove and save the manila envelope (containing the enclosure warning nameplate) which may be taped to the outer surface of the mounting flange.

Although all systems are factory tested and calibrated, we strongly suggest a bench test of basic functions prior to installation.

Mounting LH, RH, TM, BM & WM Configurations

1 . Transfer hole pattern of System mounting plate to intended surface.

2. Check for obstructions hindering bolt fastening, drill and ream the mounting holes before mounting the system.

3. Secure the system to the enclosure, or other mounting surface, using one (1) SMK-3 or equivalent - six (6) 3/8" x 3/4" stainless steel bolts, nuts and lock washers.

   *WM requires one (1) SMK-2 or equivalent - four (4) 3/8" x 3/4" stainless steel bolts, nuts and lock washers.

Mounting FM & PM Configurations

HELPFUL HINTS

FM and PM configurations are designed to mount through a panel cutout one (1) inch smaller than the overall height and width of the system mounting plate, using clips and fasteners provided with SMK -10. This design feature eliminates the need to drill the system mounting bolt holes in the protected enclosure.

FM configurations are intended for mounting adjacent to the protected enclosure.

PM configurations are intended for mounting through a cutout in the protected enclosure surface.

1. Transfer panel cutout pattern to the intended surface.
2. Check for obstructions that could prohibit bolt fastening or system pneumatic and electrical connections.
3. Cut panel cutout pattern on the intended surface.
4. Deburr all cutout surfaces.
5. Secure system to enclosure using SMK-10, or equivalent - ten (10) 1/4" x 3/4" stainless steel nuts, bolts, mounting clips and lock washers.

Typical Surface Mounted System
(Model 1002-LPS-LH Type Z shown)

Typical Pipe Mounted System
(Model 1002-LPS-LH Type Z shown)

Typical Panel/Frame Mounted System
(Model 1002-LPS-PM Type Z shown)

Part No. 512246 Drawing No. 129-0209a 03/09

Hardware Mounting

Optional Enclosure Protection Vent

All configurations must be mounted in a true vertical position.

The vent must be located to provide access for routine testing of the vent's flapper assembly. A minimum 8" clearance is required below the vent opening.

1. Determine the vent's mounting configuration, i.e., -00 vertical mount or -90 side mount. See photos below.
2. Determine vent location and layout vent mounting hole on the protected enclosure (as determined on page 6, "Getting Started").
3. Using a 1.375" hole saw or 1" conduit punch, drill and deburr the enclosure protection vent mounting hole.
4. Remove the hub mounting nut from the vent hub and place the hub, with O-ring intact, through the mounting hole. The O-ring must be on the outside of the protected enclosure.
5. Reinstall the hub mounting nut to the mounting hub from inside the protected enclosure and tighten.

EPV - 3 - SA - 00
Vertical Mount

EPV - 3 - SA - 90
Side Mount

Warning Nameplate(s)

An EWN (Enclosure Warning Nameplate) must be located in a prominent position on or near all enclosure accesses (doors and covers).

One (1) EWN is provided with each system, located in the manila envelope taped to the mounting flange of the system. Additional EWNs are available from Pepperl+Fuchs.

All EWNs provide labeled spaces allowing the customer to mark the protected enclosure with: 1) a T Code (temperature identification number), 2) Class, Group and Division of surrounding area, and 3) NFPA pressurization Type X, Y or Z, as may be required by plant and local codes and is required by NFPA 496.

An ETW (Enclosure Temperature Warning nameplate) must be located in a prominent position on or near all enclosure accesses (doors and covers) when the temperature of an internal component exceeds 80 percent of the ignition temperature of the flammable vapor, gas or dust involved.

An ETW warns the operator to deenergize all equipment for a specified length of time, allowing the protected equipment to cool before opening the protected enclosure. The length of time required is determined by the customer and can be factory or field engraved.

All EWNs and ETWs are furnished with an adhesive back, but should also be riveted or screwed to the protected enclosure.


WARNING - PRESSURIZED ENCLOSURE
THIS ENCLOSURE SHALL NOT BE OPENED UNLESS THE AREA IS KNOWN TO BE FREE OF FLAMMABLE MATERIALS OR UNLESS ALL DEVICES HAVE BEEN DE-ENERGIZED. POWER SHALL NOT BE RESTORED AFTER ENCLOSURE HAS BEEN OPENED UNTIL ENCLOSURE HAS BEEN PURGED IN ACCORDANCE WITH THE PURGE SYSTEM START-UP INSTRUCTIONS.
AREA CLASSIFICATION
PRESSURIZATION TYPE
TEMPERATURE CODE

Enclosure warning nameplate - Class I

WARNING - PRESSURIZED ENCLOSURE
THIS ENCLOSURE SHALL NOT BE OPENED UNLESS THE AREA IS KNOWN TO BE FREE OF FLAMMABLE MATERIALS OR UNLESS ALL DEVICES HAVE BEEN DE-ENERGIZED. POWER SHALL NOT BE RESTORED AFTER ENCLOSURE HAS BEEN OPENED UNTIL COMBUSTIBLE DUSTS HAVE BEEN REMOVED AND THE ENCLOSURE REPRESSURIZED IN ACCORDANCE WITH THE PRESSURIZATION SYSTEM START-UP INSTRUCTIONS.
AREA CLASSIFICATION
PRESSURIZATION TYPE
TEMPERATURE CODE

Enclosure warning nameplate - Class II

N F P A Code 496
I S A Code S12.4
WARNING NOTICE
THIS ENCLOSURE CONTAINS HOT COMPONENTS
ENCLOSURE SHALL NOT BE OPENED UNLESS THE AREA IS KNOWN TO BE NONHAZARDOUS OR UNLESS ENCLOSURE POWER HAS BEEN DEENERGIZED FOR THE TIME SPECIFIED BELOW.
MINIMUM COOLING TIME

Enclosure temperature warning nameplate

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Mounting Plate Dimensions



2001B-STD-LH
(Left hand configuration)



2001B-STD-RH
(Right hand configuration)



2001B-STD-TM
(Top mount configuration)



2001B-STD-BM
(Bottom mount configuration)

Part No. 512246 Drawing No. 129-0209a 03/09

Mounting Plate Dimensions (continued)



2001B-STD-WM
(Wall mount configuration)



TYPICAL -WM
MOUNTING FLANGE



2001B-STD-FM & 2001B-STD-PM
(Frame & panel mount configuration)

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS
PROTECTING YOUR PROCESS

Pneumatic Tubing Requirements

Protective Gas Supply Requirements

The protective gas supply to the protection system must be a clean, instrument quality compressed air or nitrogen and must contain no more than trace amounts of flammable gas, vapor or dust.

The protective gas supply compressor intake must originate in a nonhazardous location. Suction duct passing through a hazardous location and the protection system tubing and piping must be fabricated from noncombustible materials suitable for prevailing hazards and environmental conditions.

The protective gas supply must originate from a dedicated instrument quality compressed air header (1/2" pipe or larger), no farther than twenty (20) feet from the protection system. Local compressors and gas cylinders should not be used before consulting with Pepperl+Fuchs.

The protective gas supply to the protection system must be equipped with a tamper-proof regulator set at 5 psi maximum.

Exception: If the protected enclosure(s) is equipped with an EPV-3 Enclosure Protection Vent, the protective gas supply to the protection system must not exceed 120 psi maximum, 5 psi minimum. (See page 3, "System Specifications" for additional information concerning protective gas supply requirements.)

SC-6

NC-6

SYSTEM SUPPLY FITTINGS

EFC-4 & EFC-6

EBC-4 & EBC-6

ENCLOSURE SUPPLY & REFERENCE FITTINGS

EPC-13

MULTIPLE ENCLOSURE CONNECTION FITTING

Pneumatic Connection Requirements

ALL FITTINGS MAY BE CUSTOMER OR FACTORY FURNISHED

1. For system supply, one (1) SC-6 3/8" male straight connector or one (1) NC-6 3/8" male elbow connector or equivalent fitting per system.

   NOTE: Above fitting is required only if protection system is furnished with an optional in-line filter kit (model ILFK) accessory.

   One (1) similar fitting which will connect the inert gas supply tubing to the inert gas supply header connection point and one (1) lot of 3/8" O.D., .035" wall thickness, welded or seamless stainless steel tubing.
2. For enclosure supply, one (1) EFC-6 3/8" flush connector, or one (1) EBC-6 3/8" feed-through connector or equivalent fitting per system.
3. For enclosure reference, one (1) EFC-4 1/4" flush connector, or one (1) EBC-4 1/4" feed-through connector or equivalent fitting per system.
4. One (1) lot of 1/4" & 3/8" O.D., .035" wall thickness, welded or seamless stainless steel tubing.
5. For multiple enclosure connections, two (2) EPC-13 1" pipe mounting hubs or equivalent and 1" 150# rated pipe couplings & unions per interconnection.

   One (1) lot 150# rating 1/2" galvanized or aluminum pipe and fittings, fully reamed and unrestricted.

PM Pneumatic Connection Requirements

In addition to item numbers 1, 4, and 5 above, the following fittings are required for all PM configurations.

1. For system supply on PM configurations, one (1) additional EBC-6 or equivalent 3/8" through bulkhead fitting per system is required.
2. For atmospheric reference, one (1) PRB-4 or equivalent 1/4" female bulkhead fitting and stainless steel sintered element is required.

PRB-4

SYSTEM ATMOSPHERIC REFERENCE FITTING

Part No. 512246 Drawing No. 129-0209a 03/09

Tubing Connection Points

LH, RH, TM, BM, WM & FM Configuration Connection Points

PM Configuration Connection Points



HELPFUL HINT

Pneumatic connections are bolded.

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs

Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS
PROTECTING YOUR PROCESS

Tubing Installation

HELPFUL HINTS

All work must be performed by technicians qualified in pneumatic tubing and electrical conduit installation.

Pepperl+Fuchs recommends the use of .035" wall thickness, welded or seamless stainless steel tubing.

If flexible tubing is used, it must be installed in a manner that protects it from damage and corrosion.

Tubing LH, RH, TM, BM, WM & FM Configurations

System supply connections

1. Select or install a protective gas supply header tap, fitted with the proper tube size fitting and located within twenty (20) feet of the enclosure protection system.
2. If a service valve is placed between the protective gas supply header and the enclosure protection system, it must be installed in close proximity of the protected enclosure and be labeled in accordance with NFPA 496.
3. Select the appropriate fittings required to connect the protective gas supply to the protection system regulator as determined on page 11, “Pneumatic Tubing Requirements”.
4. Determine appropriate tubing route from the protective gas supply header to the protection system regulator.
5. Bend tubing using industrial grade benders, check tubing fit to ensure proper seating between the tubing and fittings. Fully ream all tubing ends.
6. Install tubing and tighten all fittings to fitting manufacturer’s specifications. Secure tubing to appropriate structural supports as required.

Enclosure supply & reference connections

1. Choose location for the enclosure supply connection(s) based on the requirements on page 6, “Getting Started.”
2. Place the enclosure reference connection fitting directly behind the enclosure protection system whenever possible. For systems protecting multiple enclosures in series, the enclosure reference connection fitting must be placed on the last enclosure in the series. See page 6, “Getting Started.”
3. Drill and deburr enclosure supply and reference fitting holes on the protected enclosure. Mount the fittings.
4. Determine appropriate route for the enclosure supply and reference tubing.
5. Bend tubing using industrial grade benders, check tubing fit to ensure proper seating between the tubing and fittings. Fully ream all tubing ends.
6. Install tubing and tighten all fittings to fitting manufacturer’s specifications. Secure tubing to appropriate structural supports as required.

Tubing PM Configurations

Enclosure bulkhead fittings

1. Select the fittings required to install the system supply, system supply bulkhead Fitting and atmospheric reference bulkhead fitting. See page 11, “Pneumatic Tubing Requirements.”
2. Choose location for the system supply bulkhead fitting. This fitting allows the protective gas supply to pass through the wall of a protected enclosure to the protection system’s regulator supply inlet connection.
3. Choose location for the atmospheric reference bulkhead fitting. This fitting allows the enclosure pressure gauge to reference atmospheric pressure.
4. Drill and deburr system supply and reference bulkhead fitting holes in the protected enclosure. Mount the fittings.

System supply & reference connections

1. Select or install a protective gas supply header tap, fitted with the proper tube size fitting and located within twenty (20) feet of the enclosure protection system.
2. If a service valve is placed between the protective gas supply header and the protection system, it must be in close proximity of the protected enclosure and labeled in accordance with NFPA 496.
3. Determine appropriate tubing route from the protective gas supply header to the system supply bulkhead fitting.
4. Determine appropriate tubing route from the system supply bulkhead fitting to the protection system regulator.
5. Determine appropriate tubing route from the atmospheric reference bulkhead fitting to the enclosure pressure gauge’s reference inlet connection.
6. Bend tubing using industrial grade benders, check tubing fit to ensure proper seating between the tubing and fittings. Fully ream all tubing ends.
7. Install tubing and tighten all fittings to fitting manufacturer’s specifications. Secure tubing as required.

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs

Electrical Supply Requirements

General Wiring Requirements

WARNING! This device contains electrical parts which can cause shock or injury.

All electrical connections, conduit and fittings on the protected enclosure must be suitable for the hazardous location in which they are installed. In addition, all conduit and wire must be installed in accordance with NEC as required and all relevant plant and local codes.

Conduit seals must be utilized on all electrical conduit connections and poured with an approved compound prior to operation of the protection system.

Exception: Do not use seals on conduit used as a protected "wireway" to supply protective gas to adjacent protected enclosures. The same conduit can be utilized for both electrical and pneumatic service to an adjacent protected enclosure(s), provided the conduit is oversized to allow a minimum free clearance equal to or larger than the pipe size required between multiple enclosures as stated on page 6, "Getting Started."

HELPFUL HINT

Pepperl+Fuchs recognizes it may be impractical to pour all electrical conduit seals prior to installation in the field. However, all conduit connections must be sealed for proper testing and operation of the enclosure protection system. Therefore, Pepperl+Fuchs recommends the use of temporary seals such as duct seal or masking tape for bench or shop testing, prior to final field installation.

EPCU Power Requirements

The electrical power control unit's (EPCU) electrical power source must originate from a circuit breaker or fused disconnect suitable for the hazardous location in which it is installed. The power source should be uninterrupted and the switch must be located within fifty (50) feet of the protected enclosure(s) and the enclosure protection system and be properly marked. For EPCU power specifications see page 3, "System's Specifications."

Alarm Signal Requirements

Pepperl+Fuchs strongly recommends use of the optional alarm system contacts of the EPCU, connected to an alarm system located in a constantly attended location to indicate the failure of the enclosure protection system. For EPCU alarm signal specifications see page 3, "System's Specifications."

Typical Enclosure Wiring Methods

Protected enclosures must be wired similar to explosion proof enclosures, in accordance with Article 500 of the National Electric Code - NFPA 70.

Single conductor wiring must be placed in rigid metal conduit, seal-flex conduit, or other mediums approved for use in the hazardous location surrounding the protected enclosure. Additionally, NFPA 496 requires approved conduit seals on all pressurized enclosure conduit wiring entries, in accordance with NFPA 70. Furthermore, the use of an approved conduit seal is simply the most practical way to prevent excessive leakage through conduit connections.

However, while explosion-proof enclosures require conduit seals on all cable entries, in accordance with NFPA 70, other methods of sealed cable entries that are suitable for hazardous locations can be used, such as compression glands.

In conclusion, there are two primary goals. First, the installer should ensure that all associated wiring and cable is protected by pressurization or other means, such as explosion-proof conduit or intrinsic safety barriers. Secondly, the installer must ensure that all associated conduit and wireways are sealed to conserve protective gas, unless they are used to supply protective gas to other enclosures or devices.

Typical Enclosure Wiring Connections



Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Electrical Power Control Unit

General Layout & Electrical Conduit Connections


EPCU electrical rating nameplate
Power mode selector switch
Power mode selector switch (optional mounting hole -factory use only-)
Type 7 explosion proof enclosure
LED display
Type 7 explosion proof screw cover
1/2" NPT conduit connection ports typical 6 (see important notes below)
Type 7 explosion proof breather drain (see important notes below)

IMPORTANT NOTES

For proper moisture drainage of the Type 7 enclosure, the installer must 1) move the Type 7 breather drain to one of the bottom conduit entrances or 2) use drain seals on all conduit connected to the bottom two conduit entrances.

The Type 7 breather drain is not provided or required with PM configurations.

Top two conduit entrances will be dedicated for Intrinsic Safe wiring ONLY when the EPCU is supplied with Pepperl+Fuchs' optional ISB intrinsic safety barriers.

EPCU LED Displays

Class II - Alarm Only



Class II - Alarm & Bypass

Part No. 512246 Drawing No. 129-0209a 03/09

EPCU Power Rating

EPCU Electrical Power Rating Nameplate

The EPCU (Electrical Power Control Unit) of this Type "X" purging system is offered in various styles. For proper installation and operation, begin by examining the EPCU electrical rating nameplate to identify the system input voltage and power requirements, enclosure power and alarm contact ratings and third party approval markings. Next, match the LED display of your EPCU with one of the displays shown on page 15. The EPCU LED Display will help identify the options featured on your system e.g., normal running mode or conditional bypass.


EPCU SERIAL NUMBER
REQUIRED WARNING STATEMENTS
MODEL 2000 ELECTRICAL POWER CONTROL UNIT
CAUTION: OPEN CIRCUIT BEFORE REMOVING COVER
ATTENTION: OUVRIR LE CIRCUIT AVANT D'ENLEVER LE COUVERCLE
SERIAL NO.
XXXXXX
INPUT VOLTAGE & POWER REQUIREMENTS
CSA Encl. 3
CLASS I, DIV. 1, Gr C&D
CLASS II, DIV. 1, Gr E, F, G HAS
UL & FM APPROVALS ONLY
ENCL POWER & ALARM CONTACTS ARE RATED 120/240 VAC, 20 AMPS
120 SINGLE PHASE, 60 CYCLE, 1 AMP
240 SINGLE PHASE, 50 CYCLE, 1 AMP

AREA CLASSIFICATION

Defines the area classifications for which the EPCU is suitable for operation

EPCU INPUT POWER REQUIREMENTS

Factory set at time of order

Assembled EPCU Electronics Module



Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Electrical & Pneumatic Diagrams

LH, RH, TM, BM, WM & FM Configurations



PM Configurations



Part No. 512246 Drawing No. 129-0209a 03/09

Conduit Installation

EPCU Electrical Conduit

Unplug the four unlabeled conduit entrances located on the sides and bottom of the EPCU enclosure (See page 15, "EPCU Layout" for conduit entrance layout).

The installer must mount the Type 7 drain fitting supplied with the system (except for PM configurations) in one of the bottom conduit entrances of the EPCU, or utilize drain seals on all conduit connected to the bottom two (2) conduit entrances of the EPCU.

Following the instructions listed below, install all conduit, fittings and seals (or drain seals if utilized) between the EPCU, alarm system (if utilized) and the protected enclosure(s). Plug all remaining EPCU conduit entrances.

1. Choose the location for the enclosure's electrical conduit connection(s) based on the requirements on page 14, "Electrical Supply Requirements".
2. Drill and deburr enclosure conduit fitting holes in the protected enclosure. Mount the fittings.
3. Determine appropriate route for the enclosure electrical enclosure and alarm signal conduit.
4. Measure, cut and thread conduit, check conduit fit to insure proper seating. Fully ream all conduit.
5. Install conduit and tighten all fittings to fitting manufacturers specifications. Secure conduit to appropriate structural supports as required.
6. Seal all conduit with an approved compound prior to operation of the protection system.

Optional Intrinsic Safety Barrier Conduit

Systems supplied with optional Intrinsic Safety Barriers (ISB) will be supplied with clearly labeled isolated conduit entries, a solid body wireway with snap cover and plexiglass wiring partitions. These accessories provide a fully isolated wiring path to the barrier wiring terminal located on the lower left corner of the EPCU Logic Module. All IS wiring must be isolated.

1. Choose the location for the enclosure's IS conduit connection(s) based on the requirements on page 14, "Electrical Supply Requirements".
2. Drill and deburr enclosure conduit fitting holes in the protected enclosure. Mount the fittings.
3. Determine appropriate route for the IS conduit.
4. Measure, cut and thread conduit, check conduit fit to ensure proper seating. Fully ream all conduit.
5. Install conduit and tighten all fittings to fitting manufacturers specifications. Secure conduit to appropriate structural supports as required.
6. Seal all conduit with an approved compound prior to operation of the protection system.

EPCU Conduit Connection Parts

Fitting Kits Can Be Factory Furnished

1. To connect enclosure power from the EPCU to the protected enclosure, one (1) LCK (L fitting Conduit Kit) or equivalent conduit elbow, coupling and seal fittings.
2. For EPCU to enclosure wiring connection with one (1) additional conduit connection path, one (1) TCK (T fitting Conduit Kit) or equivalent conduit tee, coupling and seal fittings.

IMPORTANT NOTE: Model LCK & TCK are offered primarily to OEMs attempting to achieve a "field ready" installation. In all cases, limited pipe fitting skills will be required. Pre-cut 150# galvanized steel pipe nipples can be acquired from local plumbing shops, but a hole saw or punch and wrenches are required to install kits.

TCK "T" Fitting Conduit Kit

LCK "L" Fitting Conduit Kit

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Power Modules & Wiring Diagram

EPCU 120/240 VAC Power Module Layout


Isolated coil voltage transformer
Power control switch cable header
Voltage input selector seader (factory set for 120 VAC power)
Pressure switch cable header
Logic module cable header
1 Amp input fuse
Redundant safe pressure relay
Rapid Exchange solenoid valve (RESV) relay
Alarm relay
RESV factory wiring terminal
Enclosure power relays
Power module wiring terminal
20 Amp enclosure power fuse

EPCU 120/240 VAC power module

VAC & VDC Power Module Electrical Wiring Diagram



* European single phase 240 VAC only.

Power and alarm terminals are feed-thru dry switch contacts.

Caution should be exercised to ensure that the EPCU wiring is properly connected.

All terminal connections to the EPCU should be wired with spade or round lugs.

Using 12 gauge maximum to 16 gauge minimum wire only, check EPCU power requirements (see page 14) and wire to the EPCU power source and alarm system (if utilized). Then route power source(s) through the EPCU power in and out terminals to all non-rated devices within the protected enclosure(s).

Part No. 512246 Drawing No. 129-0209a 03/09

Logic Module & Barrier Wiring

EPCU Logic Module & Pressure Switch Module



EPCU Logic Module

EPCU pressure switch module

Optional ISB Wiring Requirements

(-) BLUE (+) BROWN



All optional intrinsic safety (IS) wiring must be isolated from all other electrical wiring using the dedicated IS conduit entrances and wireway of the EPCU. See "Optional ISB Conduit Installation" on page 18 for more details. In addition, all wiring must be installed in accordance with the NEC and all relevant local and plant codes.

The intrinsic safety barriers are designed to function in conjunction with a customer furnished switch and SRM-4000 switch resistor module, or an NJ... NAMUR sensor. The customer supplied switch must have dry contacts which contain no inductance or capacitance.

The SRM-4000 switch resistor module and the NJ...NAMUR sensor are supplied with approximately ten (10) feet of wiring. Using 16 to 18 gauge shielded wire, the cable lengths can be extended to a maximum of 100 feet.

In all applications, the module of the switch resistor module cable must be installed as close to the customer supplied switch as possible for proper operation.

Wiring lugs are not recommended for intrinsic safety barrier wiring connections.

See page 21 for barrier operation and factory programing.

EPCU Power Control Modes

Normal Running (NR) Mode

EPCU features an on-off pushbutton power control switch to activate control functions. Switch must be depressed to initiate start-up. After completion of start-up, safe pressure must be lost or switch must be depressed to deenergize enclosure power relays.

Conditional Bypass (CB) Mode

EPCU features an on-off-bypass power control switch to activate control functions. Switch must be set to "on" position to initiate start-up. After enclosure power is energized, safe pressure must be lost or switch must be set to "off" position to deenergize enclosure power. After enclosure power is energized, switch may be set to "bypass" position, to temporarily latch enclosure power relays. A flashing LED then indicates bypass engaged, and the enclosure can then be accessed without deenergizing power (performed under specific conditions). Following access, safe pressure must be reestablished to resume normal operation. At that time, the switch may be reset to the on position, without disruption of enclosure power. Alarm relay normally deenergizes only upon loss of safe pressure, but can be factory programmed to deenergize when bypass is engaged, if specified at time of order.

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS PROTECTING YOUR PROCESS

Barriers & Field Adjustments

Optional Intrinsic Safety Barriers Description

The EPCU Logic Module can accommodate up to three intrinsic safety barriers, to interact with remote devices and affect operation of the EPCU. The barriers are installed and programmed by the factory at time of order, and they are designed to function either in conjunction with a customer furnished switch and a Pepperl+Fuchs furnished resistor network cable, or a Pepperl+Fuchs furnished proximity detector. Each barrier develops a low power signal, to create a two wire closed loop circuit. Operational status of each barrier is indicated by a green LED to show active (closed switch) status, and by a red LED to show faulted (line breakage) cable status. All barriers can be reprogrammed to duplicate other barrier functions as required, upon specific request.

Optional ISB Factory Programing

Barrier A Function - when switch opens
Disables start-up cycle
Deenergizes enclosure power and alarm relay
Functions parallel to safe pressure switch

Barrier B Function - when switch opens
Not programmed for this model - custom applications only

Barrier C Function - when switch closes
Energizes RESV Relay - custom applications only

LED Display Indicators

Power off:	Enclosure power relays deenergized
Power on:	Enclosure power relays energized
Safe pressure:	Enclosure pressure > 0.50" w.c.
Alarm active:	Enclosure pressure < 0.50" w.c.
Bypass engaged:	Control bypass active - CB mode

Field Adjustable Timer Functions

EDT (Exchange Delay Timer) (FA style only) provides a time delay to prevent Rapid Exchange solenoid valve from energizing until safe pressure can be stabilized.

SLT (Solenoid Latching Timer) (FA style only) provides a time delay to keep the Rapid Exchange solenoid valve energized until Rapid Exchange pressure is detected. If the pressure is not detected, the EPCU will reset.

RET (Rapid Exchange Timer) provides a time delay after Rapid Exchange pressure is detected, to allow four volume exchanges (ten volumes for motors) prior to energizing the enclosure power relays. In Class I areas only, if Rapid Exchange pressure is lost or interrupted during time delay cycle, the EPCU will reset.

EDT, SLT & RET Timer Settings



EDT & SLT Timer		RET Timer	
POSITION	**TIME IN SECONDS**	**POSITION**	**TIME IN MINUTES**
0	5	0	5
1	10	1	10
2	15	2	15
3	20	3	20
4	25	4	25
5	30	5	30
6	35	6	35
7	40	7	40
8	45	8	45
9	50	9	50
A	55	A	55
B	60	B	60
C	65	C	65
D	70	D	70
E	75	E	75
F	80	F	80

NOTE: Power must be removed from the EPCU via the local disconnect switch for approximately 10 seconds for timer adjustments to reset.

EDT, SLT & RET timers are not functional on Model 2001B.

Part No. 512246 Drawing No. 129-0209a 03/09

Set-up Procedure

HELPFUL HINTS

Regulator may be in the locked position upon arrival. To adjust regulator, pull handle to outward position.

To test the vent's operation, gently prod the vent flapper open with a soft-pointed object, (example: eraser end of a pencil) ensuring that the vent valve works freely. On vertically configured vents, this can be accomplished from within the protected enclosure. Side mounted -90 configured vents can be tested by removing the pipe plug at the bottom of the mounting tee. Multiple operations require only one test per day if enclosure is not opened or left unattended.

Class II Pressurization Set-up

1. Close the enclosure pressure control regulator fully, by turning it counterclockwise (CCW).
2. Remove all traces of combustible dust from the protected enclosure using a suitable vacuum tool.
3. Check operation of enclosure pressure vent (if utilized).
4. Seal all protected enclosure(s).
5. Depress the On-Off pushbutton (NR mode) or turn selector switch to the On position (CB mode). All LEDs should illuminate fully for two seconds (self test), then all LEDs should turn off except Power Off (solid red) and Alarm Activated (flashing red) LEDs.
6. Turn enclosure pressure control regulator slowly CW to set the enclosure pressure indicator to a "safe" 1.0 inch pressure. The safe pressure and timer running LEDs should be on, the alarm active LED should turn off. Check for a 0.50 to 0.55 inch trip point by slowly stroking the indicator from 0.40 to 1.0 inch readings. The safe pressure, alarm active and timer running LEDs should turn on and off when the indicator reads between 0.50 and 0.55 inches.

   NOTE: If pressure setting is difficult to stabilize or set, see page 24, "Troubleshooting Procedures."
7. Having ensured that the safe pressureand timer running LEDs are functioning properly, start-up procedures located on page 23 may now be followed to step through a complete start up cycle, ensuring that the system functions normally during all phases of operation.



Model 2001B-STD-LH
Front View

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS
PROTECTING YOUR PROCESS

Operating Sequence

⚠ **WARNING! Do not exceed a “safe” pressure with the enclosure pressure control regulator.**

Operators must follow step-by-step sequence of the start-up instructions nameplate on the protection system.

Do not use the bypass modes without first securing a "hot work" permit.

Never leave the system unattended in bypass modes.

Pressurization Operation

With the inert gas supply on, RET Timer set properly, EPCU power and alarm system energized (if utilized).

1. Carefully read start-up instruction nameplate on system.
2. Check operation of the enclosure protection vent (model EPV-3, if utilized), opening it manually several times. See page 22, “Helpful Hint.”
3. Remove all traces of combustible dust.
4. Seal protected enclosure(s).
5. Depress the on-off pushbutton (NR mode) or turn selector switch to the on position (CB mode). Each LED should illuminate fully for two seconds, then all LEDs should turn off except power off (solid red) and alarm activated (flashing red) LEDs.
6. Turn enclosure pressure control regulator slowly CW to set the enclosure pressure indicator to a "safe" 1.0 inch pressure. The safe pressure and timer running LEDs should be on, the alarm active LED should turn off.

   NOTE: If the safe pressure or timer running LEDs blink on and off or "flicker" during this cycle, EPCU will reset RET timer.
7. Ensure the protection system enclosure pressure indicator maintains a “safe” 1.0 inch pressure for one (1) minute. Readjust nclosure pressure control regulator if required.
8. If "safe" 1.0 inch pressure is lost, the EPCU will deenergize enclosure power and activate alarm system (if utilized).

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs

Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS
PROTECTING YOUR PROCESS

Troubleshooting Procedures

Problem or Fault	Possible Causes	Corrective Action
Enclosure pressure control regulator will not hold a "safe" 1.0 inch pressure.	Leakage around gasketing, covers, seams, piping and tubing connections, conduit connections and electrical conduit seals of the enclosure.	Tighten enclosure latches: Where tightening is not feasible, and gasketing materials are not practical, holes or gaps can be closed with silicone sealant applied from inside the protected enclosure.
Enclosure pressure indicator reading is difficult to stabilize.	Insufficient enclosure leakage or opening of the venturi orifice is crimped too small.	Remove the orifice, cut off the crimped end and ream the tube, then recrimp and reinstall the tube to note effect. As tube is shortened, reamed, and recrimped, sensitivity decreases, allowing easier adjustment of setpoint on the enclosure.
Enclosure pressure indicator "drifts" up or down from the "safe" pressure setting.	Application involves a small, tightly sealed enclosure and/or a fluctuating protective gas supply.	Pre-regulate the protective gas supply upstream of the enclosure protection system to 5 psi maximum. For dramatic fluctuations in the protective gas supply, it may be necessary to utilize a self-relieving low flow precision regulator to pre-regulate the protective gas supply.
Enclosure pressure indicator reads a "safe" pressure but the safe pressure LED is not illuminated.	Conduit seal between EPCU and protected enclosure is not poured or is leaking pressure back into the EPCU. EPCU breather drain is clogged (all systems except PM configurations). Safe pressure switch is out of calibration.	With area positively known to be non-hazardous, remove screw cover of the EPCU and attempt a complete start-up procedure. If the system works properly, check enclosure power conduit seal for leakage and the EPCU breather drain for blockage. If the system does not operate properly, calibrate the safe pressure switch. Calibrate by slowly adjusting clockwise to decrease the setpoint, and counterclockwise to raise the setpoint. (Do not attempt to calibrate the switch until all efforts to make the switch respond properly have failed)
Problems persists, or if the system does not appear to be operating properly.	Persisting problems.	Contact Pepperl+Fuchs Applications/Customer Service Department at (330) 486-0002 for more information.

This section covers the most common problems documented with this system. Any problems not covered in this section should be addressed directly to our factory. Please address all service needs to:

Pepperl+Fuchs, Inc.
Customer Service Department

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs
Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com
PEPPERL+FUCHS
PROTECTING YOUR PROCESS

Warranty Terms and Conditions

PEPPERL+FUCHS STANDARD 24-MONTH WARRANTY

1. Limited Warranty. Pepperl + Fuchs, Inc. (“P+F") warrants Purge Units and components for Purge Units manufactured by P+F (“Product" or “Products") to be free from defects in material and workmanship under Normal Use for a period of twenty-four (24) months from the date of shipment of such Products from P+F’s warehouse or place of manufacture (or from P+F’s authorized representative or distributor). Only the original purchaser of such Products (the “Customer") shall be entitled to the benefit of the foregoing Limited Warranty. No representative, agent or salesman of P+F is authorized to give or provide any warranty or make any representation contrary to or in addition to the foregoing Limited Warranty.

2. Inspection and Claims. Customer must inspect and test all Products upon receipt. All claims under the Limited Warranty provided herein must be made within thirty (30) days of the discovery of the defect. Customer must obtain shipping instructions from P+F prior to returning any Product, which Product must be returned at Customer’s expense in accordance with P+F’s instructions.

3. Limitations and Exclusions. “Normal Use" shall mean use and operation within rated capacities, at the correct voltage, and with any required maintenance as provided in the applicable P+F Operating Manuals. The Limited Warranty provided herein does not apply to (i) any Products which have been altered or modified in any way or disassembled by the Customer or anyone else, (ii) any Products which have been subject to misuse, negligence or accident, or improperly installed, changed, substituted or replaced, (iii) any part or component not manufactured by P+F, or (iv) any part or component that is subject to wear or consumption. For parts or components not manufactured by P+F, the Customer or any other user or owner shall have only the warranty provided by the manufacturer of such part or component. The Limited Warranty set forth herein is also subject to the following:

   (1) The Limited Warranty is limited to electronic and mechanical performance only, as expressly detailed in the product specifications, and does not apply to cosmetic appearance;

   (2) The Limited Warranty shall not apply to any cables attached to, or integrated with, any Products.

   (3) The Limited Warranty shall not apply to any Products which are stored, or utilized, in harsh environmental or electrical conditions outside P+F’s written specifications.

   THE LIMITED WARRANTY SET FORTH HEREIN IS THE ONLY WARRANTY MADE BY P+F WITH RESPECT TO THE PRODUCTS. IT IS EXPRESSLY AGREED AND UNDERSTOOD THAT P+F MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. EXCEPT FOR THE LIMITED WARRANTY SET FORTH HEREIN, THERE IS NO OTHER WARRANTY, EXPRESS, IMPLIED OR STATUTORY; AND THERE IS NO AFFIRMATION OF FACT OR PROMISE BY P+F WITH REFERENCE TO THE PRODUCTS. IN NO EVENT SHALL P+F BE LIABLE FOR ACTUAL OR ANTICIPATED LOST PROFITS OR FOR INCIDENTAL OR CONSEQUENTIAL OR PUNITIVE DAMAGES OR FOR DAMAGES RESULTING FROM BUSINESS INTERRUPTION, OR INJURY OR DEATH OF PERSONS, OR INJURY TO PROPERTY. P+F’S LIABILITY ON ANY CLAIM OF ANY KIND ARISING OUT OF, CONNECTED WITH OR RESULTING FROM THE DESIGN, MANUFACTURE, SALE, REPAIR OR OPERATION OF A PRODUCT, SHALL NOT EXCEED THE PRICE ALLOCABLE TO THAT PRODUCT OR THE PART THEREOF WHICH GIVES RISE TO THE CLAIM. THE REMEDY SET FORTH IN THIS LIMITED WARRANTY CONSTITUTES THE SOLE AND EXCLUSIVE REMEDY OF THE CUSTOMER. P+F SHALL NOT BE LIABLE FOR PENALTIES OF ANY DESCRIPTION.

4. Limitation of Remedies. In the event of P+F’s liability, whether on this Limited Warranty or based on contract, tort (including, but not limited to, negligence and strict liability) or otherwise, Customer’s sole and exclusive remedy will be limited to, at P+F’s option, the repair or replacement (f/o/b P+F’s place of manufacture) by P+F of any non-conforming items for which claim is made by Customer in accordance with paragraph 2, or the repayment of the portion of the purchase price paid by Customer attributable to the non-conforming item.

5. Responsibility of Customer: Safety and Protection Precautions. P+F takes great care to design and build reliable and dependable Products; however, some Products can fail eventually. Customer must take precautions to design its equipment to prevent property damage and personal injury in the unlikely event of a failure. AS A MATTER OF POLICY, P+F DOES NOT RECOMMEND THE INSTALLATION OF PRODUCTS AS THE SOLE DEVICE FOR THE PROTECTION OF PERSONNEL OR PROPERTY AND, THEREFORE, THE CUSTOMER SHOULD BUILD IN REDUNDANCY OR DUAL CONTROL USING APPROVED SAFETY DEVICES FOR THESE APPLICATIONS.

6. Conflicts. In the event there is any conflict between the provisions of this Limited Warranty and any provisions contained in any orders, offers, acceptances or other writings or statements provided or made by Customer to P+F, the provisions of this Limited Warranty shall prevail, and the contract between P+F and the Customer shall be deemed formed only upon the provisions set forth in this Limited Warranty, and any additional or conflicting provision inserted by Customer shall be of no force or effect.

Part No. 512246 Drawing No. 129-0209a 03/09

System Maintenance

Regular Maintenance

Drain the protection system regulator frequently and clean system with nonsolvent cleaning agents only.

Long-Term Maintenance

Calibrate the enclosure pressure indicator to 0 inches by venting the purge pressure reference port and the protected enclosure to atmosphere and adjusting the calibration screw in the lower center portion of the indicator's face.

Fully open the enclosure pressure control regulator, to blow out any deposits around the tip of the valve and to ensure that the enclosure protection vent is operating properly, then carefully readjust system according to the set-up procedure and operating sequence on pages 22 and 23. Replace or tighten stem packing nut as required to prohibit stem packing leakage.

Carefully disassemble the enclosure protection vent by loosening the two bottom hex nuts that hold the unit together.

(DO NOT REMOVE CAP NUTS ON TOP OF VENT BODY)

Carefully clean the flapper valve and vent body seats with warm soap and water, being careful not to extend the vent valve beyond its normal opening point, and being careful not to exert any stress on the valve hinge.

Examine the entire protection system and the protected enclosure(s), and replace any defective parts during routine shutdown of the protected enclosure(s). Parts are available from Pepperl+Fuchs on immediate notice as required.

MAINTENANCE SCHEDULE

Date	Work performed	Performed by

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs

Pepperl+Fuchs Group www.pepperl-fuchs.com
USA: +1 330 486 0002 pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222 pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091 pa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS
PROTECTING YOUR PROCESS

Systems Identification & Application Information

Date of installation _____

Unit serial # _____

Item _____

Customer P.O.# _____

Customer project# _____

Service _____

Type _____

Features _____

Application _____

Notes: _____

Part No. 512246 Drawing No. 129-0209a 03/09

Subject to modifications without notice
Copyright Pepperl+Fuchs

Pepperl+Fuchs Group
www.pepperl-fuchs.com
USA: +1 330 486 0002
pa-info@us.pepperl-fuchs.com
Germany: +49 621 776 2222
pa-info@de.pepperl-fuchs.com
Singapore: +65 6779 9091
pa-info@sg.pepperl-fuchs.com

PEPPERL+FUCHS
PROTECTING YOUR PROCESS

PROCESS AUTOMATION – PROTECTING YOUR PROCESS

For over a half century, Pepperl+Fuchs has provided new concepts for the world of process automation. Our company sets standards in quality and innovative technology. We develop, produce, and distribute electronic interface modules, Human-Machine Interfaces and hazardous location protection equipment on a global scale, meeting the most demanding needs of industry. Resulting from our world-wide presence and our high flexibility in production and customer service, we are able to offer complete individual solutions – wherever and whenever you need us. We are the recognized experts in our technologies – Pepperl+Fuchs has earned a strong reputation by supplying the world's largest process industry companies with the broadest line of proven components for a diverse range of applications.



1 **Worldwide/German Headquarters**
Pepperl+Fuchs GmbH
Mannheim · Germany
Tel. +49 621 776 2222
E-Mail: pa-info@de.pepperl-fuchs.com

2 **Asia Pacific Headquarters**
Pepperl+Fuchs PTE Ltd.
Singapore
Company Registration No. 199003130E
Tel. +65 6779 9091
E-Mail: pa-info@sg.pepperl-fuchs.com

3 **Central/Western Europe & Africa Headquarters**
Pepperl+Fuchs N.V.
Schoten/Antwerp · Belgium
Tel. +32 3 6442500
E-Mail: pa-info@be.pepperl-fuchs.com

4 **Middle East Headquarters**
Pepperl+Fuchs M.E (FZE)
Dubai · UAE
Tel. +971 4 883 8378
E-Mail: pa-info@ae.pepperl-fuchs.com

5 **North/Central America Headquarters**
Pepperl+Fuchs Inc.
Twinsburg · Ohio · USA
Tel. +1 330 486 0002
E-Mail: pa-info@us.pepperl-fuchs.com

6 **Northern Europe Headquarters**
Pepperl+Fuchs GB Ltd.
Oldham · England
Tel. +44 161 6336431
E-Mail: pa-info@gb.pepperl-fuchs.com

7 **Southern/Eastern Europe Headquarters**
Pepperl+Fuchs Elcon srl
Sulbiate · Italy
Tel. +39 039 62921
E-Mail: pa-info@it.pepperl-fuchs.com

8 **South America Headquarters**
Pepperl+Fuchs Ltda.
São Bernado do Campo · SP · Brazil
Tel. +55 11 4339 9935
E-Mail: pa-info@br.pepperl-fuchs.com

www.pepperl-fuchs.com

PEPPERL+FUCHS
PROTECTING YOUR PROCESS

Subject to modifications • © 2009 PEPPERL+FUCHS, INC. • Printed in USA • Part No. 512246 Drawing No. 129-0209a (TDOCT1363_ENG) 03/09